



# Knock-Down Spray Texture

## APPLICATION INSTRUCTIONS

### **SUPER-KRETE PRODUCTS REQUIRED:**

- S-12000 Heavy Duty Degreaser™
- S-1300 Pene-Krete®
- S-9300 Bond-Kote® Gray and S-9302 Bond-Kote® White
- S-11000 Ure-Kote™ Paint or S-9500 Series Color Stain™
- Super-Krete Sealer\*

### **SURFACE PREPARATION**

The surface to be coated shall be clean, free of all coatings and contaminants and of sufficient porosity to allow the penetration of the products in order to create a co-adhesive bond with the concrete. New concrete shall be allowed to cure for 28 days. Refer to the ***Super-Krete Products Surface Preparation Guide*** for detailed instruction on properly preparing concrete substrates to receive coatings.

#### **STEP 1:**

Apply (1) application of S-9300 Bond-Kote Gray over the entire surface by squeegee application or cement trowel.

#### **STEP 2:**

Apply (1) application of S-9302 Bond-Kote White over the entire deck by compressor and spray texture hopper gun and immediately knock down the texture using a cement trowel, fresno or crazy trowel.

#### **STEP 3:**

Apply (2) applications of S-11000 Ure-Kote acrylic-urethane deck paint over the entire surface.

### **PROTECTIVE SEALING**

The surface to be coated shall be clean, free of all coatings and contaminants and of sufficient porosity to allow the penetration of the products in order to create a co-adhesive bond with the concrete. New concrete shall be allowed to cure for 28 days. Refer to the ***Super-Krete Products Sealer Selection Guide*** for detailed instruction on properly preparing concrete substrates to receive coatings.