

Supra-Seal System

APPLICATION INSTRUCTIONS

SUPER-KRETE PRODUCTS REQUIRED:

- 8400 Supra-Seal PLUS
- 8350 Supra-Seal VOC

MOISTURE VAPOR EMISSIONS TESTING

All interior concrete floors are subject to possible moisture vapor emission and/or excessive alkalinity that could ultimately cause coating failure. Prior to application, calcium chloride moisture testing should be conducted according to ASTM 1869-04.

SURFACE PREPARATION

Surface must be clean, dry and profiled prior to installation of primer. Acceptable methods for preparation are diamond grinding or acid etching. If acid etching, follow APF written instructions. Concrete must have a minimum surface profile ICRI CSP 1, or a texture similar to 150 grit sand paper.

APPLICATION OF PRIMER

The primer for this system is **8400 Supra-Seal PLUS** or **8350 Supra-Seal VOC**. Apply one coat using a 3/8" nap roller or a low-pressure pump up sprayer. If you are using a roller, apply from 5 gallon pail or roller pan – do not pour the material directly onto the concrete. Coverage rate should be 250-350 sq. ft. per gallon depending on the substrate texture. The primer coat may be reduced up to 25% with acetone or xylene. Dry time between coats will be 2-4 hours depending upon conditions.

APPLICATION OF FINISH COAT

The topcoat for this system is **8400 Supra-Seal PLUS** or **8350 Supra-Seal VOC**. Apply one coat using a 3/8" nap roller or a low-pressure pump up sprayer. If you are using a roller, apply from 5 gallon pail or roller pan – do not pour the material directly onto the concrete. Coverage rate should be 250-350 sq. ft. per gallon depending on the substrate texture. Allow coating to cure for 48 hours prior to returning to service.